

Универсално дистанционно управление за телевизор LG с Magic Motion

1. За да откажете сдвояването на дистанционното Magic Remote:

Натиснете и задръжте едновременно бутоните /HOME и /BACK, докато светне индикаторът, за да изтриете информацията за сдвояване на предишното дистанционно управление със съществуващия телевизор.

2. За да сдвоите дистанционното управление Magic Remote:

Натиснете гласовия бутон, телевизорът ще покаже да натиснете бутона за колелцето (OK) 

Забележка: моля, работете с дистанционното управление в съответствие с горепосочената последователност: първо разкарайте магическото дистанционно управление.

Спецификации

Работно разстояние: Повече от 8 метра

Изисквания на Power: DC 3V

Тип батерия: 1,5V батерии тип AA

Доставчик/дистрибутор

Sunnysoft s.r.o.

Kovanecká 2390/1a

190 00 Прага 9

Чешка република

www.sunnysoft.cz

English

1. To unpair the Magic Remote:

Press and hold /HOME and /BACK buttons at the same time till the indicator light is on in order to clear the pairing information of the former remote with the existing TV.

2. To pair the Magic Remote:

Press Voice Button, the TV will indicate to press the Wheel (OK) Button. 

Noted: please operate the remote according to above sequence: unpair the magic remote first of all.

Specifications

Operable distance:
More than 8 metres

Power toquirements:
DC 3V

Battery type:
1.5V AA battries

