




Инструкции за употреба



FA14

Моля, прочетете внимателно тези инструкции преди употреба. Уверете се, че го използвате в строго съответствие с изискванията, посочени в ръководството, и го съхранявайте правилно за бъдещи справки.

Описание на



- | | |
|----------------------|------------------|
| ① Изход за въздух | ④ Вход за въздух |
| ② Бутон за | ⑤ Тип-С вход |
| ③ включване/скорост | |
| Индикаторна светлина | |

Инструкции преди употреба

1. Преди да включите, проверете продукта и захранващия кабел за повреди, уверете се, че са в добро и ги сглобете съгласно инструкциите.
2. Преди да заредите продукта, проверете дали напрежението на използваното съответства на етикета на продукта.

3. Не разглобявайте, не модифицирайте и не ремонтирайте продукта, за да токов удар и пожар, и го ремонтирайте в сервизния център, посочен от оригиналния търговец или производителя.

Използвайте

А. Как да го използвате

Внимателно разгънете лопатките на вентилатора наляво и надясно, като изходът за въздух е насочен нагоре. около врата си, натиснете бутона за захранване/скорост и вентилаторът ще започне да работи, издухвайки хладен въздух към главата ви за освежаващо изживяване.

В. Превключвател за захранване/скорост

Натиснете за кратко бутона за захранване/скорост, за да влезете в режим първа степен/втора степен/трета степен/четвърта степен/пета степен/изключване; продължително натискане на която и да е степен ще изключи директно вентилатора.



С. Статус на индикатора

Индикатор	Значение на
Бялата светлина продължава да свети	Състояние на пълно зареждане
Бялата светлина бавно премигва	Състояние на зареждане
Бялата светлина мига веднъж	Скорости на превключване
Бялата светлина продължава да мига	Батерията е твърде слаба
Бялата светлина мига три пъти	Батерията е изтощена и не може да работи

Д. Почистване на продукта

1. Преди да почистите продукта, се уверете, че захранването е изключено.
2. Избършете тялото на вентилатора и изхода за въздух със суха кърпа.
3. Никога не почиствайте електрически компоненти (напр. двигател, превключвател и др.) с вода или други течности.
4. Не докосвайте захранването и електрическите компоненти с мокри ръце или с мокра кърпа.
5. Отстранете своевременно праха или чуждите предмети в отвора за , за да предотвратите навлизането на прах във въздушната кухня.

Изваждане на батерията

Преди да изхвърлите продукта, батерията трябва да се извади от него. Продуктът трябва да бъде изключен, преди да извадите батерията. Батериите трябва да се безопасно в съответствие с разпоредбите на мястото на продажба.

1. Използвайте инструмента, за да отстраните щепсела и долния винт, след което отворете вътрешния капак и отстранете долния винт (Фигура 1).
2. Използвайте инструмента, за да отворите външния капак (Фигура 2).
3. Издърпайте конектора на батерията и извадете, като я изхвърлите безопасно в съответствие с местните разпоредби (Фигура 3).



Фигура 1



Фигура 2



Фигура 3

Известие за безопасност

За да се гарантира безопасността при употреба и да се предотвратят наранявания и повреди

на вашата собственост и на собствеността на другите, моля, спазвайте следните мерки за безопасност. Неправилната употреба без спазване на предупрежденията за безопасност може да доведе до инциденти.

01. Този продукт не е детска играчка, моля, уверете се, че бебетата и децата не играят с този продукт като с играчка. Децата под 14-годишна възраст трябва да го използват под родителски надзор.

02. Този продукт не е предназначен за употреба от потребители (включително деца) с недостатъчна физиология, възприятия и умствени способности, опит или знания, освен ако не го използват безопасно под надзора или със знанието на лицето, отговорно за тяхната безопасност.

03. Не духайте директно върху човешкото тяло за продължителни периоди от време, особено за и деца, за да избегнете физически дискомфорт.

04. Когато използвате, не поставяйте пръсти, остри предмети, метални предмети и т.н., които могат да причинят повреда на продукта и риск от удар или нараняване.
05. Избягвайте да използвате мокри ръце, мокри кърпи и други щепсели по време на работа, за да предотвратите токов удар.
06. Този продукт не е водоустойчив, не използвайте вода за изплакване на продукта директно или в банята, тежка влага, места за съхранение на вода за употреба. Моля, изсушете водата на повърхността навреме, преди да се опитате да я включите за употреба. Не използвайте напълно напоена и с вода вътре.
07. Не покривайте изхода и входа за , като например висящи дрехи, кърпи, облекло и други предмети, за да предотвратите повреда на продукта.
08. Забранете използването и съхранението в среда с висока температура (над 60°C) и в затворени помещения, като оранжерии, строителни площадки, камини, открити автомобилни купета и други среди, които ще предизвикат деформация на пластмасата, пламък с вятър ще предизвика пожар, експлозия на батерията и други неизправности и инциденти.
09. Не компресируйте, не разглобявайте и не монтирайте батерията за продължителни периоди от време.
в среда с висока температура (60 °C или повече), в противен случай съществува риск от изтичане на течност или експлозия.
10. Ако потребителите използват захранващ адаптер за зареждане, входното номинално напрежение и токът на захранващия адаптер трябва да бъдат в диапазона 5,0 V/2,0 A и задължителните национални сертификати за безопасност трябва да бъдат изпълнени преди употреба.
11. Този продукт използва литиево-йонна батерия, тя няма функция за памет, презареждането или прекомерното разреждане ще повлияе на живота на продукта, моля, зареждайте навреме и изключете захранването, когато е напълно заредено. След продължително зареждане на устройството (повече от 3 месеца) не се използва, моля, заредете напълно.
12. Ако по време на употреба възникнат дим, пожар и други неизправности, незабавно изключете захранването, за да спрете да използвате инструмента и го изпратете на търговеца или производителя за решение, не го разглобявайте сами, за да избегнете опасност.
13. Не огъвайте и не дърпайте захранващия кабел по време на зареждане, за да лош контакт.

Параметри на продукта

Марка: JisuLife

Модел: FA14

Име на : Вентилатор за врата Life3

Мощност: 5.0/ 2.0A

Капацитет на батерията: 4000 mAh

(14,8Wh/3,7V) Батерия: литиево-йонна батерия

Време за зареждане: 3,5 - 4,5 ч.

Време за работа: 2 - 13,5 часа в зависимост от оборудването/използването)

Тегло на продукта: приблизително 270 g

Размер на продукта: 206× 200× 60 мм

Съдържание на пакета

Вентилатор за врата Life3 x1

USB-C захранващ кабел x1

Ръководство x1

Съдържанието на това ръководство за потребителя и техническите спецификации на продукта могат да бъдат променяни без предизвестие.

Доставчик/дистрибутор

Sunnysoft s.r.o.
Kovanecká 2390/1a
190 00 Прага 9
Чешка република
www.sunnysoft.cz

Производител: Shenzhen Jisu Technology Co., Ltd

Address: 301, Bui ding A, No.8, Changjiangpu 2 Road, He'ao


Community, Yuanshan Street, Longgang District, Shenzhen

URL: www.jisulife.com

Tel: 400-011-8812




User Guide



FA14

Please read this manual carefully before use. Be sure to use it in strict accordance with the requirements of the manual, and keep the manual properly for future use.

Appearance Description



Air Outlet - - - - - ①
Switch/Gear Button - - - - - ②
Indicator Light - - - - - ③

Air Inlet - - - - - ④
Type-C Input Port - - - - - ⑤

Precautions Before Use

1. Please check the product and power cord for any damage and make sure they are in good condition and assemble them according to the instructions before powering them on.
2. Before charging the product, please check whether the voltage of the power supply used is consistent with the product label.

3. Please do not disassemble, modify or repair the product to avoid electric shock and fire accidents, and ask the service station designated by the original seller or manufacturer for repair.

How To Use


A. How To Use It

Gently spread the fan blades left and right, with the air outlet facing upwards, hang it around your neck, press the power/speed button, and the fan starts working, blowing cool air towards your head, providing a refreshing experience.



B. Power/Speed Switch

Short press the power/speed button to cycle through the first gear/second gear/third gear/fourth gear/fifth gear/shut-down mode; long press at any gear to shut down directly.



C. Indicator Status Description

Indicator Status	Meaning
White light always on	Fully charged state
White light flashes slowly	State of charge
The white light flashes once	Gears switching
White light keeps flashing	Battery is too low
White light flashes 3 times	Battery low and cannot work

D. Product Cleaning

1. Before cleaning the product, please make sure the power is disconnected.
2. Wipe the fan body and air outlet with a dry cloth.
3. Never clean electrical components (such as the motor, power switch, etc.) with water or other liquids.
4. Do not touch the power supply and electrical parts with wet hands or wet cloth.
5. Please clean up the dust or foreign objects in the air outlet in time to avoid dust falling into the air cavity.


Remove The Battery

The battery must be removed from the product before disposing of the product; The product must be powered off before removing the battery; Batteries should be safely disposed of in accordance with the regulations of the place of sale.

1. Use a tool to remove the screw plug and the lower screw, then pry open the inner casing and remove the lower screw (Figure One).
2. Use a tool to pry open the outer casing (Figure Two).
3. Pull out the battery connector and remove the battery, dispose of it safely in accordance with local regulations (Figure Three).



(Figure One)



(Figure Two)



(Figure Three)

Safety Precautions

To ensure the safety of use and to avoid injury and property damage to you and others, please observe the following safety precautions; Incorrect use without observing the safety warnings may lead to accidents.

01. This product is not a child's toy, please ensure that infants and children do not play with this product as a toy; Children under 14 years of age, please use it under the supervision of a guardian.
02. This product is not intended for use by users (including children) with inadequate physiology, perception, mental

ability, experience, or knowledge, unless used safely under the supervision or knowledge of a person responsible for their safety.

03. Please do not blow directly on the human body for a long time, especially the elderly and children, to avoid physical discomfort.
04. When using, please do not put fingers, sharp objects and metal objects, etc., which will cause product failure and the risk of electric shock, or injury.
05. When using, prohibit the use of wet hands, wet towels and other plugging power to avoid electric shock.
06. This product is not waterproof, please do not use water to directly rinse the product or in the bathroom, heavy moisture, water storage places to use; surface water, please dry in time to dry before trying to turn on the use; completely soaked and internal water into the prohibition of re-use.
07. Do not cover the air outlet and air inlet, such as hanging clothes, towels, clothes, and other items, so as not to cause product failure.
08. Prohibit the use and storage in high temperature (higher than 60 °C) environments and confined spaces, such as greenhouses, construction sites, fireplaces, exposed car rooms and other environments, which will cause plastic deformation, flame with the wind to cause fire, battery explosion and other failures and accidents.
09. Do not squeeze, disassemble the battery or place the battery in a high-temperature environment (60°C and above) for a long time, otherwise there may be a risk of liquid leakage or explosion.
10. If consumers use the power adapter to charge, the power adapter input rated voltage and current should be within 5.0V== 2.0A, and the national mandatory safety certification

before use.

11. This product uses lithium-ion battery, no memory function, overcharge or overdischarge will affect the service life of the product, please charge in time and disconnect the power after full charge, long time (more than 3 months) do not use please fully charge.
12. If there is smoke, fire and other failures in use, please immediately turn off the power to stop using, and send it to the dealer or manufacturer to deal with, do not disassemble themselves to avoid danger.
13. Do not bend or pull the power cord during charging to avoid poor contact.

Product Parameters

Brand: JisuLife

Product Model: FA14

Product Name: Neck Fan Life3

Input: 5.0V== 2.0A

Battery Capacity: 4000mAh(14.8Wh/3.7V)

Battery Cell: Lithium-ion Battery

Charging Time: 3.5-4.5h

Operating Time: 2-13.5h(dependent on different gears/use scenarios)

Product Weight: about 270g

Product Size: 206×200×60mm

Packing Accessories

Neck Fan Life3 * 1

USB-C Charging Cable * 1

Manual * 1

The contents in this user manual and the technical specification of the product will be changed without prior notice.

Manufacturer: Shenzhen Jisu Technology Co., Ltd

Address: 301, Building A, No.8, Changjiangpu 2 Road, He'ao Community, Yuanshan Street, Longgang District, Shenzhen

URL: www.jisulife.com

Tel: 400-011-8812



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired

"NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help."