ANC



USER MANUAL

Active noise-canceling headphones

Introduction









Left Right



It can be stretch

Operation

Power ON/OFF:

Push the switch " to open & off power.

ANC Mode ON/OFF:

Please quickly press play button 2 times to turn it on or off.

Pairing Mode: Once the headset is on, Then blue and red light will Flash, It will be ready to pair, Search the BT name "ANC Headphone" & "D-806 ANC" & "D-808ANC" your Device, Once connected headset Will Send out a sound "Connected".

Select Song: Please press the "+" button for a long time to go to The next song and "-" button for a long time to go to the previous song.

Volume Adjustment: Please press the "+" button for a short time to increase the volume and "-" button for a short time to decrease the volume.

Calling Mode: Please press the play button to answer the call, Press again to hang up. If you want to reject the call, Please press The button for a long time.

To activate Voice Assistan (Siri):

After connected ,Please press play button 3 times to activate, Such as: Siri、google ,firstly your phone should support.

Low delay Game mode / Music mode change:

Press the play button 4 times to change.

AUX line in (3.5mm socket):

Please use it in power off model, Will to save battery power and get better sound quality.

Charging Mode: Please charge in time when the battery is low.

The red led will light up while charging and turn off when fully charged.

Specification

Style:	Headset/over ear/on ear
BT Version:	V5.3
Audio range:	20Hz-20KHz
Frequency Range:	2.402 GHZ ~ 2.480
BT profiles :	HSP, HFP, A2DP, AVRCP
Emission range:	≥ 15 M
Active Noise Canceling:	Support
Voice Assistant Siri:	Support
Low delay game mode:	Support
Play time-Normal mode:	About 40 hours
Play time-ANC Mode:	About 30 hours
Stand-by time:	1000 hours
Li PO Battery:	3.7V/400mAh
Noise frequency width:	50-800Hz
Noise reduction depth:	20dB±2
Aux line in:	3.5mm socket
Speaker(bass):	Φ 40mm/32 Ω
Microphone:	-42dB±3
Speaker Sensitivity:	About 118dB ±3
SNR:	≥95dB

Safety Precautions

- Keep the device out of extreme heat and humid.
- Please do not split the headphones.
- Please do not overcharge. If don't use it for a long time, please.
 still to charge battery from time to time in order to protect it.
- Please wear the headsets correctly during use, and adjust the angle of the headsets in the pinna, to make it achieve: the best comfortable and sound quality.
- If the Headphones can't work, Plese try to keep pressing the Music play buttons for 9 seconds to reset then start up.